



Don Bellini
FINE CHINA



Hotels and restaurants' most favourite collection - Don Bellini Fine China is crisp and ivory which goes casual for everyday, or sophisticated for formal dinners. It is an overture of grace and simplicity. Dressing up or down with ease, its elegant appearance belies its everyday durability. The collection offers an extensive array of pieces to choose from.

WWW.DONBELLINI.COM



Don Bellini

Don Bellini is a manufacturer, marketer and distributor that specializes in high quality porcelain and stainless steel cutlery. The brand offers bone china, fine china, colour glaze porcelain and 18/10 stainless steel cutlery. The large assortment of tableware Don Bellini offers fulfils the needs of both catering and domestic users.

With headquarter located in Hong Kong, an international export hub, where Don Bellini's manufacturing plants and warehouses are closely located, prompt delivery of products is guaranteed at a competitive cost. Together with a vastly experienced sales team in the industry, Don Bellini is well-equipped to bring the best service and products to its customers.

DON BELLINI BESPOKE / MADE TO ORDER

We collaborate with customers to create beautifully bespoke and unique tableware. From concept and design, through to samples and full production, we will work with you throughout the process to ensure your ideas become a reality.

We are especially experienced in printing logos and patterns on glassware and porcelain. We welcome orders with a Minimum Quantity of 300 pieces or above on this process.

HANDLING & CARE

Don Bellini porcelain is practical and ideal for everyday use. It is dishwasher-safe, oven-safe and microwave-safe - unless it is decorated with precious metals.

All Don Bellini porcelain pieces are easy to clean using the soft side of a scrub sponge, warm water and regular dishwashing liquids. However, avoid using the abrasive side of the sponge, which might scratch or damage the surface of the product.

Our products are also dishwasher-safe. Make sure to select a low-temperature program and do not exceed the recommended amount of detergent. Load all of the pieces securely in the dishwasher to prevent items from touching each other or they may get chipped.

ORIENTAL CUISINE



On photo:

DB3010123
Dinner plate 9" | 23 cm

DB3020011
Bowl 4.5" | 11 cm 9 oz | 260 ml

DB3030122
Tea cup & saucer 7 oz | 220 ml

DB306DD90
Divided soy dish 3.5" | 9 cm

DB3020913
Soup cup with lid
5" | 12.5 cm 11 oz | 320 ml

DB306CR06
Chopstick rest

DB3019030
Dish 12" x 4" | 30 x 10 cm

DB3013023
Dish 8.75" x 5.25" | 22.5 x 13 cm

DB3010131
Round platter 12" | 30.5 cm

DB3010026
Rolled rim dinner plate 10" | 25.5 cm

WESTERN CUISINE

On photo:

DB3010131
Round platter 12" | 30.5 cm

DB3010123
Dinner plate 9" | 23 cm

DB3010515
Rim plate 6" | 15 cm

DB3020110
Soup cup 4" | 10 cm 10 fl oz | 300 ml

DB3019030
Dish 12" x 4" | 30 x 10 cm

DB3010015
Rolled rim bread plate 6" | 15 cm

DB306SU90
Sugar packet holder
3.5" x 2.5" x 1.5" | 9 x 6.5 x 4.5 cm

DB3030018
Cappuccino cup & saucer
6 oz | 180 ml

DB3050015
Creamer 5 oz | 150 ml

DB3043035
Tea pot 12 oz | 350 ml

DB306PS33
Pepper shaker





Rolled rim bread plate 6" | 15 cm

DB3010015

Inner box: 12 pcs
Outer carton: 96 pcs



Rolled rim dessert plate 7" | 18 cm

DB3010018

Inner box: 12 pcs
Outer carton: 72 pcs



Rolled rim dessert plate 8" | 20 cm

DB3010020

Inner box: 6 pcs
Outer carton: 48 pcs



Rolled rim dinner plate 9" | 23 cm

DB3010023

Inner box: 6 pcs
Outer carton: 36 pcs



Rolled rim dinner plate 10" | 25.5 cm

DB3010026

Inner box: 6 pcs
Outer carton: 24 pcs



Square coupe plate 5" | 13 cm

DB3012013

Inner box: 10 pcs
Outer carton: 120 pcs



Square coupe plate 6" | 16 cm

DB3012016

Inner box: 12 pcs
Outer carton: 72 pcs



Bread plate 6.5" x 6.5" | 16.5 x 16.5 cm

DB3012017

Inner box: 6 pcs
Outer carton: 72 pcs



Square coupe plate 7" | 18 cm

DB3012018


Inner box: 10 pcs
Outer carton: 60 pcs



Square coupe plate 8" | 20 cm

DB3012020

Inner box: 6 pcs
Outer carton: 48 pcs



Square flat plate 8" | 20 cm

DB3012320

Inner box: 6 pcs
Outer carton: 36 pcs



Square flat plate 10" | 25 cm

DB3012325


Inner box: 4 pcs
Outer carton: 24 pcs



Square flat plate 12" | 31 cm

DB3012331


Inner box: 4 pcs
Outer carton: 16 pcs



Rectangular flat plate 12" | 29 cm

DB3013229

Inner box: 6 pcs
Outer carton: 36 pcs



Rectangular flat plate 14" | 36 cm

DB3013236

Inner box: 4 pcs
Outer carton: 20 pcs



Square plate 8" | 21 cm

DB3012121

Inner box: 6 pcs
Outer carton: 36 pcs



Square plate 10" | 26 cm

DB3012126

Inner box: 6 pcs
Outer carton: 24 pcs



Square platter 12" | 31 cm

DB3012131


Inner box: 3 pcs
Outer carton: 18 pcs



Rectangular plate 10" | 26 cm

DB3013126

Inner box: 8 pcs
Outer carton: 48 pcs



Rectangular plate 12" | 31 cm

DB3013131

Inner box: 6 pcs
Outer carton: 24 pcs



Slanting bowl 4" | 10 cm

DB3020210

Inner box: 12 pcs
Outer carton: 144 pcs



Slanting bowl 4.5" | 12 cm

DB3020212

Inner box: 8 pcs
Outer carton: 96 pcs



Slanting bowl 6" | 15 cm

DB3020215

Inner box: 5 pcs
Outer carton: 60 pcs



Slanting bowl 7" | 17 cm

DB3020217

Inner box: 6 pcs
Outer carton: 48 pcs



Slanting bowl 8" | 21 cm

DB3020221

Inner box: 4 pcs
Outer carton: 24 pcs





Rolled rim dinner plate 11" | 28 cm

DB3010028

Inner box: 3 pcs
Outer carton: 24 pcs



Rolled rim round platter 12" | 30.5 cm

DB3010031

Inner box: 3 pcs
Outer carton: 18 pcs



Rim plate 6" | 15 cm

DB3010115

Inner box: 12 pcs
Outer carton: 96 pcs



Dessert plate 7" | 18 cm

DB3010118

Inner box: 12 pcs
Outer carton: 72 pcs



Dessert plate 8" | 20 cm

DB3010120

Inner box: 6 pcs
Outer carton: 48 pcs



Square coupe plate 9" | 23 cm

DB3012023

Inner box: 5 pcs
Outer carton: 30 pcs



Square coupe plate 10" | 26 cm

DB3012026

Inner box: 4 pcs
Outer carton: 24 pcs



Square coupe plate 11" | 28 cm

DB3012028

Inner box: 4 pcs
Outer carton: 20 pcs



Square coupe plate 12" | 31 cm

DB3012031


Inner box: 4 pcs
Outer carton: 20 pcs



Square coupe plate 14" | 36 cm

DB3012036

Inner box: 3 pcs
Outer carton: 12 pcs



Rectangular flat plate 16" | 40 cm

DB3013240

Inner box: 4 pcs
Outer carton: 16 pcs



Rectangular flat plate 18" | 47 cm

DB3013247

Inner box: 3 pcs
Outer carton: 12 pcs



Square plate 7" | 17 cm

DB3012417

Inner box: 6 pcs
Outer carton: 48 pcs



Square plate 8" | 20 cm

DB3012420


Inner box: 6 pcs
Outer carton: 36 pcs



Square plate 10" | 25 cm

DB3012425

Inner box: 4 pcs
Outer carton: 20 pcs



Rectangular plate 14" | 36 cm

DB3013136

Inner box: 4 pcs
Outer carton: 20 pcs



Rectangular plate 16" | 41 cm

DB3013141

Inner box: 3 pcs
Outer carton: 12 pcs



Rectangular plate 18" | 46 cm

DB3013146

Inner box: 3 pcs
Outer carton: 12 pcs



Thick rim oval plate 10" | 26 cm

DB3011026


Inner box: 6 pcs
Outer carton: 36 pcs



Thick rim oval plate 12" | 31 cm

DB3011031

Inner box: 6 pcs
Outer carton: 36 pcs



Slanting bowl 9" | 23 cm

DB3020223

Inner box: 3 pcs
Outer carton: 18 pcs



Oval bowl 8" | 21 cm

DB3021021

Inner box: 6 pcs
Outer carton: 48 pcs



Oval bowl 9" | 23 cm

DB3021023

Inner box: 6 pcs
Outer carton: 36 pcs



Oval bowl 10" | 25 cm

DB3021025

Inner box: 4 pcs
Outer carton: 24 pcs



Oval bowl 12" | 31 cm

DB3021031

Inner box: 4 pcs
Outer carton: 16 pcs





Dinner plate 9" | 23 cm

DB3010123

Inner box: 6 pcs
Outer carton: 36 pcs



Dinner plate 10" | 25.5 cm

DB3010126

Inner box: 6 pcs
Outer carton: 24 pcs



Dinner plate 11" | 28 cm

DB3010128

Inner box: 3 pcs
Outer carton: 24 pcs



Round platter 12" | 30.5 cm

DB3010131

Inner box: 3 pcs
Outer carton: 18 pcs



Square platter
11.5" x 11.5" | 29.5 x 29.5 cm

DB3012330

Inner box: 3 pcs
Outer carton: 12 pcs



Dish 5.25" x 3.5" | 13 x 9 cm

DB3023013

Inner box: 12 pcs
Outer carton: 96 pcs



Towel dish 6.5" | 16 cm

DB306TD16

Inner box: 10 pcs
Outer carton: 120 pcs



Square rim plate 7.5" | 19 cm

DB3012223

Inner box: 6 pcs
Outer carton: 36 pcs



Square rim plate 9.5" | 24 cm

DB3012228

Inner box: 4 pcs
Outer carton: 24 pcs



Square rim plate 11.5" | 29 cm

DB3012235

Inner box: 4 pcs
Outer carton: 16 pcs



Square plate 12" | 31 cm

DB3012431

Inner box: 3 pcs
Outer carton: 12 pcs



Deep plate 9" | 23 cm 15 oz | 450 ml

DB3010323

Inner box: 6 pcs
Outer carton: 24 pcs



Deep plate 10" | 25.5 cm 20 oz | 600 ml

DB3010326

Inner box: 3 pcs
Outer carton: 18 pcs



Deep plate 11" | 28 cm 27 oz | 800 ml

DB3010328

Inner box: 3 pcs
Outer carton: 18 pcs



Deep plate 11" | 29 cm

DB3010329

Inner box: 4 pcs
Outer carton: 20 pcs



Thick rim oval plate 14" | 36 cm

DB3011036

Inner box: 4 pcs
Outer carton: 20 pcs



Thick rim oval plate 16" | 41 cm

DB3011041

Inner box: 3 pcs
Outer carton: 12 pcs



Thick rim oval plate 18" | 46 cm

DB3011046

Inner box: 3 pcs
Outer carton: 12 pcs



Thick rim oval plate 20" | 51 cm

DB3011051

Inner box: 2 pcs
Outer carton: 8 pcs



Thick rim oval plate 22" | 57 cm

DB3011057

Inner box: 2 pcs
Outer carton: 6 pcs



Sauce dish 3" X 2.5" | 8 X 6 cm

DB306SD80

Inner box: 6 pcs
Outer carton: 144 pcs



Sushi/canape dish 12" x 4.7" | 30.5 x 12 cm

DB3013031

Inner box: 6 pcs
Outer carton: 36 pcs



Sushi/canape dish 14" x 5.5" | 36 x 14 cm

DB3013036

Inner box: 3 pcs
Outer carton: 18 pcs



Dish 8.75" x 5.25" | 22.5 x 13 cm

DB3013023

Inner box: 6 pcs
Outer carton: 36 pcs



Dish 12" x 4" | 30 x 10 cm

DB3019030

Inner box: 6 pcs
Outer carton: 36 pcs



FINE CHINA



Ramekin 55ml / 2.8" | 7 cm

DB306RK05

Inner box: 20 pcs
Outer carton: 240 pcs



Ramekin 75ml / 3" | 8 cm

DB306RK07

Inner box: 12 pcs
Outer carton: 192 pcs



Ramekin 85ml / 3.2" | 8 cm

DB306RK08

Inner box: 12 pcs
Outer carton: 144 pcs



Ramekin 140ml / 3.5" | 9 cm

DB306RK14

Inner box: 10 pcs
Outer carton: 120 pcs



Ramekin 215ml / 4" | 10 cm

DB306RK21

Inner box: 8 pcs
Outer carton: 96 pcs



Round bowl 3" | 8 cm

DB3020508

Inner box: 12 pcs
Outer carton: 180 pcs



Rice bowl 4.25" | 11 cm

DB3020511

Inner box: 10 pcs
Outer carton: 120 pcs



Rice bowl 4.5" | 12 cm

DB3020512

Inner box: 8 pcs
Outer carton: 96 pcs



Noodle bowl 7" | 18 cm

DB3020018

Inner box: 4 pcs
Outer carton: 24 pcs



Noodle bowl 8" | 21 cm

DB3020021

Inner box: 4 pcs
Outer carton: 24 pcs



3 oz | 100 ml Coffee cup & saucer

DB3030010

Inner box: 6 sets
Outer carton: 72 sets



6 oz | 180 ml Cappuccino cup & saucer

DB3030018

Inner box: 6 sets
Outer carton: 48 sets



8 oz | 250 ml Tea cup & saucer

DB3030025

Inner box: 6 sets
Outer carton: 36 sets



Jumbo mug 14 oz | 420 ml

DB3030042

Inner box: 6 pcs
Outer carton: 36 pcs



6 oz | 180 ml Tea cup & saucer

DB3030118

Inner box: 6 sets
Outer carton: 48 sets



Mug 8 oz | 250 ml

DB3031025

Inner box: 6 pcs
Outer carton: 48 pcs



Mug 11 oz | 320 ml

DB3030032

Inner box: 6 pcs
Outer carton: 48 pcs



Mug 12 oz | 350 ml

DB3030035

Inner box: 6 pcs
Outer carton: 48 pcs



Mug 13 oz | 380 ml

DB3030138

Inner box: 6 pcs
Outer carton: 48 pcs



Mug 10 oz | 310 ml

DB3030031

Inner box: 6 pcs
Outer carton: 48 pcs





Don Bellini



Noodle bowl 8.25" | 20 cm

DB3020320

Inner box: 6 pcs
Outer carton: 36 pcs



Noodle bowl 8.75" | 22 cm

DB3020322

Inner box: 4 pcs
Outer carton: 24 pcs



Noodle bowl 9.25" | 24 cm

DB3020324

Inner box: 4 pcs
Outer carton: 24 pcs



Noodle bowl 11.5" | 29 cm

DB3020329

Inner box: 3 pcs
Outer carton: 24 pcs



Round deep plate 9" | 23 cm

DB3010423

Inner box: 3 pcs
Outer carton: 24 pcs



Bowl 3.5" | 9 cm

DB3020009

Inner box: 6 pcs
Outer carton: 72 pcs



Rice bowl 4.2" | 11 cm

DB3020611

Inner box: 12 pcs
Outer carton: 144 pcs



Rice bowl 4.5" | 11 cm

DB3020411

Inner box: 8 pcs
Outer carton: 96 pcs



Bowl 4.5" | 11 cm

DB3020011

Inner box: 6 pcs
Outer carton: 72 pcs



Bowl 6" | 15.5 cm

DB3020016

Inner box: 6 pcs
Outer carton: 48 pcs



4 oz | 110 ml Coffee cup & saucer

DB3033011

Inner box: 6 sets
Outer carton: 48 sets



5 oz | 160 ml Coffee cup & saucer

DB3033016

Inner box: 6 sets
Outer carton: 48 sets



7 oz | 220 ml Tea cup & saucer

DB3030022

Inner box: 6 sets
Outer carton: 36 sets



7 oz | 220 ml Tea cup & saucer

DB3030122

Inner box: 6 sets
Outer carton: 36 sets



3 oz | 90 ml Coffee cup & saucer

DB3030009

Inner box: 6 sets
Outer carton: 48 sets



Mug 16 oz | 460 ml

DB3030046

Inner box: 6 pcs
Outer carton: 48 pcs



Mug 13 oz | 380 ml

DB3030038

Inner box: 6 pcs
Outer carton: 48 pcs



Creamer 2 oz | 50 ml

DB3050005

Inner box: 12 pcs
Outer carton: 144 pcs



Creamer 3 oz | 100 ml

DB3050010

Inner box: 12 pcs
Outer carton: 144 pcs



Creamer 5 oz | 150 ml

DB3050015

Inner box: 6 pcs
Outer carton: 72 pcs



Dishwasher and Microwave Safe



Round deep plate 10" | 25.5 cm

DB3010426

Inner box: 3 pcs
Outer carton: 18 pcs



Bowl 5.75" x 5.75" | 14.5 x 14.5 cm
12 oz | 345 ml

DB3022015

Inner box: 6 pcs
Outer carton: 48 pcs



Bowl 6.5" x 6.5" | 16.5 x 16.5 cm
22 oz | 650 ml

DB3022017

Inner box: 6 pcs
Outer carton: 36 pcs



Bowl 8.5" x 8.5" | 21.5 x 21.5 cm
44 oz | 1300 ml

DB3022022

Inner box: 3 pcs
Outer carton: 24 pcs



Dessert dish
4" x 2" | 10 x 5 cm 6 oz | 180 ml

DB3020710

Inner box: 6 pcs
Outer carton: 72 pcs



Noodle bowl 6.25" | 16 cm

DB3020416

Inner box: 5 pcs
Outer carton: 60 pcs



Soup bowl 8.25" | 22 cm

DB3020422

Inner box: 4 pcs
Outer carton: 24 pcs



Soy dish 3" | 7.5 cm

DB306SD75

Inner box: 24 pcs
Outer carton: 144 pcs



Soy dish 4" | 10 cm

DB306SD10

Inner box: 12 pcs
Outer carton: 144 pcs



Multi-use saucer 5.5" | 14 cm

DB306SC14

Inner box: 12 pcs
Outer carton: 96 pcs



5 oz | 160 ml Tea cup & saucer

DB3030016

Inner box: 6 sets
Outer carton: 48 sets



7 oz | 200 ml Tea cup & saucer

DB3032020

Inner box: 6 sets
Outer carton: 36 sets



Milk jar 17 oz | 500 ml

DB306MJ50

Inner box: 6 pcs
Outer carton: 36 pcs



Teapot 25 oz | 740 ml

DB3040074

Inner box: 2 pcs
Outer carton: 24 pcs



Teapot 27 oz | 800 ml

DB3040080

Inner box: 2 pcs
Outer carton: 24 pcs



Creamer 7 oz | 200 ml

DB3050020

Inner box: 6 pcs
Outer carton: 48 pcs



Tea pot 12 oz | 350 ml

DB3043035

Inner box: 1 pc
Outer carton: 36 pcs



Tea pot 17 oz | 500 ml

DB3043050

Inner box: 1 pc
Outer carton: 36 pcs



Teapot 27 oz | 800 ml

DB3040180

Inner box: 2 pcs
Outer carton: 24 pcs



Teapot 40 oz | 1200 ml

DB3040112

Inner box: 2 pcs
Outer carton: 24 pcs





Baking pot 15 oz | 450 ml

DB3070045

Inner box: 3 pcs
Outer carton: 36 pcs



Soup cup with lid
4" | 10 cm 8 fl oz | 250 ml

DB3090910

Inner box: 6 pcs
Outer carton: 36 pcs



Soup cup with lid
5" | 12.5 cm 11 oz | 320 ml

DB3020913

Inner box: 6 pcs
Outer carton: 36 pcs



Soup cup 4" | 10 cm 10 oz | 300 ml

DB3020910

Inner box: 4 pcs
Outer carton: 48 pcs



Soup cup 4.25" | 11 cm 11 oz | 330 ml

DB3020111

Inner box: 4 pcs
Outer carton: 48 pcs



Soup cup 4" | 10 cm 10 fl oz | 300 ml

DB3020110

Inner box: 4 pcs
Outer carton: 48 pcs



Chopsticks rest

DB306CR83

Inner box: 60 pcs
Outer carton: 480 pcs



Chopstick rest

DB306CR06

Inner box: 24 pcs
Outer carton: 288 pcs



Pepper shaker

DB306PS33

Inner box: 4 pcs
Outer carton: 144 pcs



Salt shaker

DB306SS33

Inner box: 4 pcs
Outer carton: 144 pcs



Spoon 4" | 10.5 cm

DB306SP11

Inner box: 24 pcs
Outer carton: 288 pcs



Spoon 5" | 13 cm

DB306SP13

Inner box: 24 pcs
Outer carton: 288 pcs



Spoon 5.5" | 13.5 cm

DB306SP14

Inner box: 24 pcs
Outer carton: 288 pcs



Snack dish 4" x 2" | 10.5 x 5 cm

DB306SN11

Inner box: 12 pcs
Outer carton: 288 pcs



Dish 5.5" x 3" | 14 x 7.5 cm

DB3013014

Inner box: 12 pcs
Outer carton: 96 pcs



Chinese tea cup 5 oz | 150ml

DB3030015

Inner box: 12 pcs
Outer carton: 144 pcs



Saucer 5" | 13cm for chinese tea cup

DB3039013

Inner box: 12 pcs
Outer carton: 144 pcs



Dessert bowl 3" | 8 cm

DB3020709

Inner box: 8 pcs
Outer carton: 96 pcs



Square sauce dish 3" | 8 cm

DB306SD83

Inner box: 12 pcs
Outer carton: 144 pcs



Snack dish with handle 4" | 10 cm

DB306SN09

Inner box: 24 pcs
Outer carton: 288 pcs



Sugar packet holder
3.5" x 2.5" x 1.5" | 9 x 6.5 x 4.5 cm

DB306SU90

Inner box: 6 pcs
Outer carton: 72 pcs



Soy bottle 6 oz | 170 ml

DB306SB17

Inner box: 6 pcs
Outer carton: 96 pcs



4 oz | 130 ml Mustard pot with spoon

DB306MP13

Inner box: 6 pcs
Outer carton: 72 pcs



Divided soy dish 3.5" | 9 cm

DB306DD90

Inner box: 12 pcs
Outer carton: 144 pcs



Divided dish 5.5" x 3" | 14.5 x 7.5 cm

DB306DD15

Inner box: 6 pcs
Outer carton: 72 pcs





Base plate for snack/dessert dish 11" | 28 cm

DB306SN26

Inner box: 6 pcs
Outer carton: 72 pcs



Caviar set 11" | 27 cm

DB306CV27

Inner box: 3 sets
Outer carton: 18 sets



Caviar set 13" | 34 cm

DB306CV34

Inner box: 3 sets
Outer carton: 18 sets



Spoon for caviar set 11" | 28 cm

DB306CS10

Inner box: 24 pcs
Outer carton: 288 pcs



Spoon for caviar set 13" | 33 cm

DB306CS12

Inner box: 24 pcs
Outer carton: 288 pcs



Snack/dessert dish 3.5" | 9 cm

DB306SN08

Inner box: 6 pcs
Outer carton: 72 pcs



Bowl 4" | 10.5 cm 3 oz | 100 ml

DB3029011

Inner box: 12 pcs
Outer carton: 72 pcs



Bowl 5" | 12.5 cm 6 oz | 190 ml

DB3029013

Inner box: 12 pcs
Outer carton: 72 pcs



Dish 4" | 10 cm

DB3029010

Inner box: 6 pcs
Outer carton: 144 pcs



Square dish
3" x 3" x 1.25" | 7.5 x 7.5 x 3.5 cm
3 oz | 90 ml

DB3022008

Inner box: 6 pcs
Outer carton: 72 pcs



Snack/dessert dish
4" x 3" x 1.5" | 10 x 7 x 4 cm
3 oz | 100 ml

DB306SN10

Inner box: 6 pcs
Outer carton: 144 pcs





Don Bellini
FINE CHINA



@DonBelliniTableware

WWW.DONBELLINI.COM

G/F, On Wing Building, 59 Bonham Strand East, Sheung Wan, Hong Kong
Tel: (852) 2544 1503 Fax: (852) 2815 2175
Email: info@donbellini.com

Copyright © 2018 Don Bellini. All rights reserved.